

MID AMERICA



MOTORWORKS

Pursue your passion here

P.O. Box 1368 • Effingham, IL 62401 • Worldwide: 217-540-4200  
FAX: 217-540-4800 • Call Toll-Free U.S. & Canada 800-500-1500  
Web: [www.mamotorworks.com](http://www.mamotorworks.com) • E-mail: [mail@mamotorworks.com](mailto:mail@mamotorworks.com)

---

## Suggested Installation Instructions for #100-004 Jack Insert

---

1. Set parking brake. Place manual transmissions in gear, or automatic transmission into park.
2. **ALWAYS** use jack stands
3. Remove cradle from floor jack.
4. Place our Jack Insert into floor jack.
5. Locate elongated holes in frame, 19" forward of rear wheel well and 17" rearward of front wheel well.
6. Insert tip into jacking points and jack up Corvette.

